

The GRAZIER SYSTEM'S STD CORNER BRACE ASSEMBLY

(Read "Tip" at bottom of this page FIRST.)

**Locate Pieces
for 3 Std Corners:**

3 Posts

6 Brace Legs

6 U-brackets

12 bolts


12 self-locking nuts

Place two U-brackets onto each Post between cotter pins.

Secure each with one bolt & self-locking nut ("back bolts").

Tighten just so that U-brackets are still able to be rotated by hand.

"U Brackets"




"Back Bolts"

2

Spread the U Brackets apart so that they are about 90 degrees from one another (2).

Tip: Orient U Brackets so they roughly center on rope hangers, as shown (2), and put top one to left, bottom to right.

"Front Bolts"



Insert the Front Bolts through the U Brackets and Brace Legs as shown (3), in same direction as Back Bolts, and attach a self-locking nut.

(Be sure the Anchor Points point downward.)

"Post"

Tighten the Front Bolts so that the Brace Legs will swivel up and down easily, but will not be "floppy loose."

"Brace Leg"

You might want to tighten the Back Bolts just a tad now, too, so that the U Brackets will still swivel on the Post, but not be loose. (Note: The U Brackets will bend a bit; this is normal.)

"Finished Corner"

"Anchor Points"

Tip: All this can be done on your living room floor or a bench, but it can be made somewhat easier if you go outside and stand the Post upright by sticking it into the ground first. This will help hold it steady while you attach the Brace Legs.